



既有刀模列表

序號	盒型/ 內外徑	長 X 寬 X 高			
	五折盒 / 飛機盒				
1	五折盒#B浪 (外徑)	38	34	12	
2	五折盒#B浪 (內徑)	45	30	10	
3	五折盒#E浪 (外徑)	29	23.5	10.5	
4	五折盒#B浪 (外徑)	31	21.5	11.5	
5	五折盒#B浪 (外徑)	30	15.5	10	
6	五折盒#E浪 (外徑)	28	13.5	10.5	
7	五折盒#E浪 (外徑)	19	13	7	
8	五折盒#B浪 (外徑)	30	10	10	
9	五折盒#B浪 (外徑)	35	28.5	12	
10	五折盒#B浪 (外徑)	48	38	11.3	
11	五折盒#B浪 (外徑)	29	23.5	10.5	
12	五折盒#B浪 (外徑)	23.5	15	8	
13	五折盒#B浪 (內徑)	29	19	11.5	
14	五折盒#B浪 (外徑)	35	28.5	10	
15	五折盒#B浪 (外徑)	56	25	12	
16	五折盒#B浪 (內徑)	28	20	9.5	
17	五折盒#B浪 (內徑)	28	13.5	9.5	
19	五折盒#B浪 (外徑)	36	29.5	10	
21	五折盒#B浪 (內徑)	33	16	13	
22	五折盒#B浪 (外徑)	25	20	11	
23	五折盒#B浪 (內徑)	24	19	14	
24	五折盒#B浪 (內徑)	25	23	11	
25	五折盒#B浪 (內徑)	45	45	12	
27	五折盒#B浪 (內徑)	60	40	5	
28	五折盒#B浪 (內徑)	24	17	9.4	
29	五折盒#B浪 (外徑)	33.5	23	5	
30	五折盒#E浪 (外徑)	33.5	23	5	
31	五折盒#B浪 (外徑)	26.2	25	5.4	
32	五折盒#B浪 (內徑)	21.3	14.3	5.5	
33	五折盒#B浪 (內徑)	27	17	10	
34	五折盒#B浪 (內徑)	19.2	19.2	7.8	
37	五折盒#E浪 (內徑)	20	12	8	
38	五折盒#E浪 (外徑)	15.9	11	5.5	
39	五折盒#E浪 (內徑)	27.5	10.5	8.6	
40	五折盒#B浪 (內徑)	23	20	7	

41	五折盒#B浪 (外徑)	33.8	20.6	9.1	
42	五折盒#E浪 (內徑)	27	13	6.5	
43	五折盒#B浪 (內徑)	23	10.5	6	
44	五折盒#E浪 (內徑)	23	17	10	
45	五折盒#E浪 (內徑)	13	9.5	6.5	
46	五折盒#B浪 (內徑)	35	28	7.9	
47	五折盒#B浪 (內徑)	35	28	4	
49	五折盒#B浪 (內徑)	25	25	5	
50	五折盒#B浪 (外徑)	26.5	24.3	7.5	
51	五折盒#B浪 (外徑)	42.5	30	7	
53	五折盒#B浪 (內徑)	28	15	11	
54	五折盒#B浪 (外徑)	57.5	42	10.2	
55	五折盒#B浪 (外徑)	31	25.5	10	
56	五折盒#B浪 (內徑)	21	19	9	
57	五折盒#B浪 (內徑)	28.5	18	8	
58	五折盒#E浪 (內徑)	27	19	7.5	
59	五折盒#B浪 (內徑)	35.5	22	11	
60	五折盒#B浪 (外徑)	23.5	11.6	6.4	
61	五折盒#B浪 (外徑)	15	12	7	
62	五折盒#B浪 (外徑)	24	17	11.5	
63	五折盒#B浪 (內徑)	28.5	22	10	
64	五折盒#E浪 (外徑)	26	10.5	6.5	
65	五折盒#E浪 (內徑)	16	11	5.5	
66	五折盒#B浪 (外徑)	155.8	15.4	5.4	
67	五折盒#E浪 (內徑)	14	12	7	
69	五折盒#B浪 (外徑)	21.5	20	5.5	
70	五折盒#E浪 (外徑)	15.5	6	5.5	
71	五折盒#B浪 (內徑)	122	13	6	
73	五折盒#E浪 (內徑)	19	12	4.5	
74	五折盒#B浪 (外徑)	32.4	23	9.5	
75	五折盒#B浪 (外徑)	42.5	30	5	
76	五折盒#B浪 (外徑)	30	15	5	
77	五折盒#B浪 (外徑)	23.5	21.5	6.2	
79	五折盒#B浪 (外徑)	35	21	12	
80	五折盒#B浪 (外徑)	32	22.8	10.3	
81	五折盒#B浪 (內徑)	22	19	9	
82	五折盒#B浪 (外徑)	30	20	5	
83	五折盒#B浪 (外徑)	38.8	31.3	11.9	
84	五折盒#B浪 (外徑)	24	12	10	
86	五折盒#E浪 (外徑)	42	30	12	

87	五折盒#B浪 (内徑)	30	30	15	
88	五折盒#E浪 (外徑)	46	22	10	
89	五折盒#E浪 (外徑)	35	35	10	
91	五折盒#B浪 (外徑)	22.8	14	6.5	
92	五折盒#B浪 (外徑*長條型*)	24.7	9.5	7.9	
93	五折盒#B浪 (内徑)	19.5	16.5	5.5	
94	五折盒#E浪 (外徑)	18	18	11.5	
96	五折盒#B浪 (内徑)	38	29	10	
97	五折盒#B浪 (内徑)	45.5	31.8	10	
98	五折盒#B浪 (外徑)	47.5	33	12	
99	五折盒#B浪 (外徑)	62.5	39.5	12	
100	五折盒#B浪 (外徑)	35	23	9.5	
101	五折盒#B浪 (外徑)	40	27	15	
102	五折盒#B浪 (内徑)	22	16	10	
103	五折盒#B浪 (内徑)	22	22.5	14.5	
104	五折盒#B浪 (外徑)	22	15	12.5	
105	五折盒#B浪 (外徑)	28	19	12.5	
106	五折盒#B浪 (外徑)	38.4	25.6	5.6	
107	五折盒#B浪 (外徑)	36.5	30	11.5	
108	五折盒#B浪 (外徑)	69.5	13.6	13.5	
109	五折盒#B浪 (外徑)	51.5	13.6	13.5	
110	五折盒#B浪 (内徑)	38.8	39.4	14.5	
111	五折盒#B浪 (外徑)	42.4	21.6	15.6	
112	五折盒#B浪 (内徑)	47.7	23.9	14.7	
114	五折盒#B浪 (内徑)	19	13	7	
115	五折盒#B浪 (外徑)	22	27	7	
116	五折盒#B浪 (外徑)	28.5	19.5	3	
118	五折盒#E浪 (外徑)	16.8	11.3	4.8	
119	五折盒#B浪 (外徑)	45	30	18	
120	五折盒#B浪 (外徑)	39	29.5	6.5	
121	五折盒#B浪 (外徑)	49	33	12.5	
122	五折盒#B浪 (外徑)	20.4	11.6	6.1	
123	五折盒#B浪 (外徑)	20	14	7.5	
124	五折盒#B浪 (外徑)	32.5	25.6	8.6	
125	五折盒#B浪 (外徑)	29	20	12	
126	五折盒#B浪 (外徑)	29.9	21.6	5.1	
127	五折盒#B浪 (外徑)	40.5	27	8	
128	五折盒#E浪 (外徑)	11.5	11	5	
130	五折盒#B浪 (外徑)	8.8	5.4	3	
132	五折盒#E浪 (外徑)	23.5	15	8	

134	五折盒#B浪 (內徑) (有人字繩孔)	35	25	12	
135	五折盒#B浪 (外徑)	19.6	30.1	10.2	
136	五折盒#B浪 (外徑)	25.4	16.6	11	
139	五折盒#B浪 (外徑)	40	30	15	
140	五折盒#B浪 (外徑)	30	18	12	
141	五折盒#B浪 (外徑)	32.1	20.8	12	
142	五折盒#B浪 (外徑)	18.1	13.2	6.2	
148	五折盒#B浪 (內徑)	30	25	8	
150	五折盒#B浪 (外徑)	30	18	10	
151	五折盒#B浪 (外徑)	21.8	15.4	5.4	
152	五折盒#B浪 (內徑)	19	19	8	
153	五折盒#B浪 (外徑)	30	18	10	
154	五折盒#B浪 (內徑)	29	27	11	
156	五折盒#B浪 (外徑)#含舌扣	21.8	15	6.2	
157	五折盒#B浪 (外徑)#含舌扣	23.5	21.5	6.2	
158	五折盒#B浪 (外徑)#含舌扣	23.5	21.5	12.6	
159	五折盒#B浪 (外徑)	27.4	22.6	8.6	
161	五折盒#B浪 (外徑)	18.3	21.9	8.4	
163	五折盒#B浪 (內徑)	30	30	8	
164	五折盒#B浪 (內徑)	33	24	7	
165	五折盒#B浪 (外徑)#含舌扣	28.5	15.9	10.3	
167	五折盒#B浪 (內徑)	30	26	5	
168	五折盒#B浪 (內徑)	18	12	4	
169	五折盒#B浪 (外徑)	15	10	6	
170	五折盒#B浪 (外徑)	38.7	23.3	12.9	
171	五折盒#B浪 (外徑)	45	35	8	
173	五折盒#B浪 (內徑)	19	13.3	4.5	
174	五折盒#B浪 (內徑)	18	16.5	12	
175	五折盒#B浪 (外徑)	20	14	7.5	
177	五折盒#B浪 (外徑)	26.1	16.2	6	
178	五折盒#B浪 (內徑)	31	23	3	
179	五折盒#B浪 (內徑)	24.5	16	7	
180	五折盒#B浪 (外徑)	24.9	15.1	7	
181	五折盒#B浪 (外徑)	21.8	15	7.4	
182	五折盒#B浪 (外徑)	25.2	23.2	7.4	
183	五折盒#B浪 (外徑)	42.5	35	10	
185	五折盒#B浪 (外徑)	29.1	19.8	8.6	
186	五折盒#B浪 (外徑)	27.2	18	11.7	
187	五折盒#B浪 (外徑)	12.6	24.8	9.8	
188	五折盒#B浪 (內徑)	18.5	17.5	8	

189	五折盒#E浪 (內徑)	24	23	7	
191	五折盒#E浪 (外徑)	25	25	10	
192	五折盒#B浪 (外徑)#含舌扣	27.6	21.8	10.2	
196	五折盒#B浪 (外徑)	31.8	17	9.1	
198	五折盒#E浪 (外徑)	15	15	4.8	
199	五折盒#B浪 (外徑)	43.5	30	10	
200	五折盒#E浪 (外徑)	36.8	29.3	8.8	
201	五折盒#B浪 (外徑)	45	30	12	
202	五折盒#B浪 (外徑)	44	15.6	15.6	
205	五折盒#E浪 (外徑)	46.6	32.4	3	
206	五折盒#卡紙 (內徑)	20	12	5	
208	五折盒#E浪 (外徑)	22.6	8.4	8	
209	五折盒#E浪 (外徑)	37.8	27.4	11.4	
210	五折盒#B浪 (外徑)	30	28	6	
211	五折盒#E浪 (外徑)	27.9	22.8	9.1	
212	五折盒#B浪 (外徑)	71.9	53.5	7.9	
213	五折盒#B浪 (外徑)	33.9	22.6	6.6	
214	五折盒#B浪 (外徑)	33.9	22.6	10.9	
215	五折盒#B浪 (外徑)	32.6	24.6	7	
216	特殊成型盒#B浪 (外徑)	45	36	14	
217	五折盒#B浪 (外徑)#含舌扣	20	8	9.7	
218	五折盒#B浪 (外徑)	39	32	18	
220	五折盒#E浪 (外徑)	30.2	25.5	6.9	
221	五折盒#E浪 (內徑)	23	19	9	
222	五折盒#B浪 (外徑)	43	27.6	15.1	
223	五折盒#B浪 (內徑)	22	20	10	
225	五折盒#E浪 (外徑)	45	30	9.5	
228	五折盒#B浪 (外徑)	43.9	31.6	13.6	
229	五折盒#B浪 (外徑)	22	10.2	8	
233	五折盒#E浪 (外徑)	37.8	28.4	5.4	
234	五折盒#B浪 (外徑)	20	10	10	
236	五折盒#E浪 (內徑)	21	21	11	
237	五折盒#E浪 (外徑)	47.8	46.4	4.4	
239	五折盒#B浪 (外徑)	46	33.6	11.6	
240	五折盒#E浪 (外徑)	35.6	22.8	9.3	
241-1	五折盒#E浪 (外徑)	30	28.6	6.8	
242	五折盒#B浪 (外徑)	35	25.2	7.1	
243	五折盒#B浪 (外徑)	39.8	21.4	5.9	
244	五折盒#B浪 (外徑)	32	21.1	7.1	
245	五折盒#B浪 (外徑)	34.4	22.6	4.6	

246	五折盒#卡紙 (外徑)	14.5	12.5	3	
247	五折盒#B浪 (外徑)	23	16.4	12.4	
248	五折盒#B浪 (內徑)	28.5	20	7.5	
249	五折盒#B浪 (外徑)	23.1	15.4	7.1	
250	五折盒#E浪 (外徑)	28.8	30.4	10.1	
251	五折盒#B浪 (外徑)	36.6	25.4	12.1	
253	五折盒#B浪 (外徑)	23	19	8	
254	五折盒#E浪 (外徑) #前側內扣	22	23	10.4	
255	五折盒#卡紙 (外徑)	18.5	13	8.5	
257	五折盒#B浪 (外徑)	18.1	13.2	6.2	
258	五折盒#B浪 (外徑)	29	20.6	6.1	
259	五折盒#B浪 (外徑)	27.4	19.1	11	
260	五折盒#E浪 (外徑)	27.4	19.1	11	
261	五折盒#E浪 (外徑)	29	19.5	9.8	
262	五折盒#B浪 (外徑)	19.1	18.9	5.6	
263	五折盒#B浪 (外徑)	21	20	11	
264	五折盒#E浪 (內徑)	28	21	9	
265	五折盒#B浪 (外徑)	13.2	10.2	3.8	
266	五折盒#E浪 (外徑)	17.8	9.4	7.9	
267	五折盒#B浪 (外徑)	34.5	24.8	9.5	
268	五折盒#E浪 (外徑)	15.8	14.2	4.9	
269	五折盒#B浪 (外徑)	32	21.6	6.6	
270	五折盒#B浪 (外徑)	24.4	19.5	9.5	
271	五折盒#E浪 (外徑)	31.8	25.4	8.4	
272	五折盒#E浪 (外徑)	26.5	17	8.5	
273	五折盒#E浪 (外徑)	20.4	12.7	9.3	
274	五折盒#卡紙 (外徑)	20	10	5	
275	五折盒#B浪 (外徑)	26.6	19.1	7.1	
276	五折盒#E浪 (外徑)	30	18	6	
277	五折盒#E浪 (外徑)	18	18	5	
278	五折盒#E浪 (內徑)	23	15	10	
279	五折盒#E浪 (外徑)	21.8	10	10.4	
280	五折盒#B浪 (外徑)	31	20	15	
281	五折盒#B浪 (外徑)	35.4	22.6	8.1	
282	五折盒#E浪 (內徑)	14	30	13	
283	五折盒#E浪 (外徑)	19	14.8	9	
284	五折盒#B浪 (外徑)	15.4	13.6	12.1	
285	五折盒#B浪 (外徑)	20.4	17.6	7.6	
286	五折盒#E浪 (外徑)	27.9	19.8	9.1	
287	五折盒#B浪 (外徑)	17.6	16.2	10.7	

288	五折盒#E浪 (外徑)	25.4	17.6	10.6	
290	五折盒#E浪 (外徑)	12.6	10.5	3.4	
291	五折盒#E浪 (外徑)	20.8	14.4	3.9	
292	五折盒#F浪 (外徑)	8	6.5	4	
293	五折盒#E浪 (外徑)	63.8	9.9	5.9	
294	五折盒#E浪 (外徑)	25.8	16.2	6.9	
295	五折盒#E浪 (外徑)	14.7	15.6	3.5	
296	五折盒#E浪 (外徑)	16.8	15.4	5.9	
297	五折盒#B浪 (外徑)	30	20	10	
298	五折盒#B浪 (外徑)	32.4	23	12.5	
299	五折盒#E浪 (外徑)	40	28	6	
300	五折盒#E浪 (外徑)	18	18.6	5.6	
半蓋鞋盒 					
1	半蓋鞋盒E浪 內徑	29	18	9.5	
2	半蓋鞋盒E浪	31	21	13	
3	半蓋鞋盒E浪	37	23	13	
4	半蓋鞋盒E浪	24	15	9	
5	半蓋鞋盒E浪	29.5	22	10.5	
全蓋盒 					
1	全蓋盒B浪 外徑	36	29.5	10	
斜蓋盒 					
1	斜蓋鞋盒E浪 無孔	30	25	12	
2	斜蓋鞋盒E浪 有圓洞孔	50	30	12	
3	斜蓋手提盒E浪 後面有提繩孔	33.2	18.4	8.1	
抽屜盒 (B浪)  抽屜盒 (卡紙)					
2	抽屜鞋盒_大 #B浪 外徑	24.5	12.5	32	
拉鍊紙盒 / 斯拉式紙盒 					
2	拉鍊飛機盒 #B浪 (外徑)	45	30	14	
3	拉鍊插底盒 #卡紙 (外徑)	12.2	6.1	13	

4	拉鍊飛機盒 #B浪 (外徑)	27.2	19.6	15.6	
5	拉鍊飛機盒 #B浪 (外徑)	37	27	8	
6	拉鍊飛機盒 #B浪 (外徑)	29.7	20.6	10.6	
7	拉鍊飛機盒 #B浪 (外徑)	40	30	15.5	
8	拉鍊飛機盒 #B浪 (外徑)	25	19	8.5	
9	拉鍊飛機盒 #B浪 (外徑)	22	16	10	
10	拉鍊A型紙箱 #B浪 (外徑)	40	30	15	
11	拉鍊飛機盒 #B浪 (外徑)	29.3	20	10	
12	拉鍊飛機盒 #E浪 (外徑)	33	23	5	
13	拉鍊飛機盒 #E浪 (外徑)	35	26	10	
14	拉鍊飛機盒 #E浪 (外徑)	44	35	10.5	
15	拉鍊飛機盒 #E浪 (外徑)	21	14	13	
16	拉鍊飛機盒 #B浪 (外徑)	20	14	6	
17	拉鍊飛機盒 #B浪 (外徑)	40	35	8	
18	拉鍊飛機盒 #B浪 (外徑)	50	45	8	
19	拉鍊插底紙箱 #B浪 (外徑)	32	14.4	25.4	
20	拉鍊飛機盒 #E浪 (內徑)	23	19.6	9	
21	拉鍊飛機盒 #B浪 (外徑)	43	34	9	
22	拉鍊飛機盒 #E浪 (外徑)	17.6	16.4	7.4	
23	拉鍊插底紙箱 #B浪 (外徑)	30	30	15	
24	拉鍊插底紙箱 #B浪 (外徑)	30	30	30	
26	拉鍊插底紙箱 #B浪 (外徑)	22.9	19.7	16.9	
27	拉鍊飛機盒 #B浪 (外徑)	43	34	14	
28	拉鍊飛機盒 #B浪 #有提繩孔 (外徑)	32	28.4	7.6	
29	拉鍊飛機盒 #B浪 (外徑)	36	31	10	
30	拉鍊飛機盒 #E浪 (外徑)	24	15	5	
31	拉鍊飛機盒 #B浪 (外徑)	36.5	30	8.1	

32	拉鍊飛機盒 #B浪 (外徑)		40	30	15	
33	拉鍊A型紙箱 #B浪 (外徑) 波浪刀		40	30	19.6	
34	拉鍊A型紙箱 #B浪 (外徑) 波浪刀		30	30	15	
35	拉鍊插底紙箱 #E浪 (外徑)		23	12.5	15.5	
36	拉鍊飛機盒 #E浪 (外徑)		26.6	22.1	13.4	
37	拉鍊飛機盒 #E浪 (外徑)		22.6	21.4	7.4	
38	拉鍊插底盒 #卡紙 (外徑)		10	10.5	12.8	
提繩五折盒 						
2	提繩五折盒 #外徑#E浪		51.5	34.5	8	
3	提繩五折盒 #外徑#E浪		30	23	7.1	
4	提繩五折盒 #外徑#B浪		38	30	9	
8	提繩五折盒 #有舌扣 #外徑#B浪		24.2	24.2	10.6	
十字盒 						
1	十字盒(有提繩孔) 外徑#B浪		44	28.5	7.1	
2	十字盒 外徑#B浪		34	30.5	7.5	
3	十字盒(有提繩孔) 外徑#B浪		40	23	8	
4	十字盒 外徑#B浪		60.7	45.2	5	
5	十字盒 外徑#B浪		32.6	31.7	4.6	
6	十字盒(塑膠提把) 外徑#B浪		42	41.6	6	
7	十字盒(塑膠提把) 外徑#B浪		52	51.6	6	
塑膠提把五折盒 						
1	塑膠手提五折盒 #外徑#含塑膠提把 #B浪		31	25	9.5	
2	塑膠手提五折盒 #外徑#含塑膠提把 #B浪		45	35	12	
4	塑膠手提五折盒 #外徑#含塑膠提把 #B浪		49.6	24.6	7.2	
5	塑膠手提五折盒 #外徑#含塑膠提把 #B浪		30.5	20	8	
6	塑膠手提五折盒 #外徑#含塑膠提把 #B浪		47.5	18.5	10.5	
10	塑膠手提五折盒 #外徑#含塑膠提把 #B浪		35.4	33.6	13.3	
11	塑膠手提五折盒 #內徑#含塑膠提把 #B浪		28.5	20	6.5	

12	塑膠手提五折盒 #內徑#含塑膠提把 #B浪	35	25	12	
17	手提五折盒 #一體成型 #外徑 #B浪	33	23	21	
18	塑膠手提五折盒 #外徑#含塑膠提把 #B浪	32.9	25	11	
19	塑膠手提五折盒 #外徑#含塑膠提把 #B浪	38	25.5	12	
20	塑膠手提五折盒 #外徑#含塑膠提把 #B浪	46.8	24.9	5.1	
21	塑膠手提五折盒 #外徑#含塑膠提把 #B浪	32.9	25.6	7.6	
雙頭插蓋 手提盒 #塑膠提把 					
1	雙頭插蓋手提盒 #外徑#B浪	40	20	60	
2	雙頭插蓋手提盒 #外徑#B浪	39.5	12.5	67.5	
3	雙頭插蓋手提盒 #外徑#B浪	37.1	13.3	60.2	
4	雙頭插蓋手提盒 #外徑#B浪	39.1	14.4	62.2	
掀蓋紙盒 					
1	掀蓋紙盒 #卡紙 #外徑 #含提繩孔	27.6	21.6	7.8	
2	掀蓋紙盒 #B浪 #外徑	20	22	7.5	
3	掀蓋紙盒 #E浪 #外徑	29.3	17.6	9.8	
4	掀蓋紙盒 #B浪 #外徑	20.8	20	9	
插底型紙盒 					
1	插底型紙盒#B浪	31.5	18.6	47.9	
2	插底型紙盒#B浪	21	21	33.5	
3	插底型紙盒#B浪	10.5	7	5	
4	插底型紙盒#B浪	9	9	30	
5	插底型紙盒#B浪	12	8	6	
6	插底型紙盒#B浪	16	8	6	
7	插底型紙盒#B浪	27	25.8	11.5	
8	插底型紙盒#B浪	23	17	11	
9	插底型紙盒#B浪	12.5	10.5	7.5	

10	插底型紙盒#B浪	10	10	28	
11	插底型紙盒#B浪	16.7	12.7	12.8	
13	插底型紙盒#B浪	25.2	15	11	
16	插底型紙盒#B浪 外徑	11.8	11.7	12	
18	插底型紙盒#B浪 外徑	11.7	11.7	16.2	
20	插底型紙盒#B浪 外徑	10	10	14.5	
22	插底型紙盒#B浪 內徑	29.5	29.5	19	
24	插底型紙盒#B浪 內徑	20.5	20.5	30.5	
26	插底型紙盒 #B浪外徑 附人字繩孔洞	40	30	20	
27	插底型紙盒#B浪 外徑	7.5	6.7	15.6	
28	插底型紙盒#B浪 外徑	8.5	7.5	11.9	
29	插底型紙盒#B浪 外徑	9.8	5.7	13	
33	插底型紙盒#F浪 外徑	7.3	7.3	15	
35	插底型紙盒#B浪 外徑 (有透氣孔)	23	13	24.8	
36	插底型紙盒 #卡紙	7	2.5	7	
39	插底型紙盒 #B浪	48	30	30	
40	插底型紙盒 #B浪	26.6	17.3	8.2	
42	插底型紙盒 #A浪	30	30	30	
43	插底型紙盒 #A浪	45	30	31	
45	插底型紙盒 #B浪	11.5	10	12.5	
46	插底型紙盒 #卡紙 #有提繩孔	17.7	17.7	13	
48	插底型紙盒 #卡紙	3.4	3.4	6.9	
50	插底型紙盒 #B浪 #外徑	9.5	9.5	9.5	
52	插底型紙盒 #卡紙	7.3	7.3	13.6	
53	插底型紙盒 #卡紙	5.5	5.5	11.8	
54	插底型紙盒 #卡紙	18.2	9.2	25.3	
55	插底型紙盒 #卡紙	12.5	11	9.5	
56	插底型紙盒 #卡紙	3.3	3.3	7.4	
57	插底型紙盒 #卡紙	3	3	8.8	
58	插底型紙盒 #卡紙 附提繩孔洞	10.5	10.5	13	
59	插底型紙盒 #B浪	40	30	20	
60	插底型紙盒 #卡紙	7	7	36.5	
61	插底型紙盒 #B浪	31	18.5	26.4	
62	插底型紙盒 #B浪	17	11.3	15.9	

63	插底型紙盒 #B浪 #外徑	15.5	7.5	23	
64	插底型紙盒 #B浪 #外徑	18.5	7.5	27	
65	插底型紙盒 #B浪 #外徑	21.5	7.5	32	
66	插底型紙盒 #B浪 #外徑	26.5	8.5	36	
67	插底型紙盒 #卡紙 #外徑	21	19	6.4	
68	插底型紙盒 #E浪 #外徑 #有提繩孔	6.2	6.2	28.7	
69	插底型紙盒 #卡紙 #外徑	6.5	5	13.5	
70	插底型紙盒 #卡紙 #外徑	13.9	9.4	3.8	
71	插底型紙盒 #F浪 #外徑	7.3	7.3	8.15	
72	插底型紙盒 #E浪 #外徑	10.4	8.9	16.2	
73	插底型紙盒 #卡紙 #外徑	3.5	3.5	10	
74	插底型紙盒 #E浪 #外徑	7.7	7.7	21.5	
76	插底型紙盒 #E浪 #外徑	12	10	11	
77	插底型紙盒 #卡紙 #外徑	7	6.5	11.5	
78	插底型紙盒 #卡紙 #外徑	8.4	5.4	12.6	
79	插底型紙盒 #E浪 #外徑 #有提繩孔	7.9	6.8	7.5	
80	插底型紙盒 #E浪 #外徑 #有提繩孔	5.2	5.1	11.5	
81	插底型紙盒 #卡紙 #外徑	10.1	6.9	12.7	
82	插底型紙盒 #卡紙 #外徑	8	6	9	
83	插底型紙盒 #B浪	15	10.5	18.3	
84	插底型紙盒 #B浪	22.1	8	23	
85	插底型紙盒 #卡紙 #外徑	5.4	5.4	12.2	
86	插底型紙盒 #E浪 #外徑	21.2	11	14.3	
87	插底型紙盒 #卡紙 #外徑	5.2	5.2	10.6	
88	插底型紙盒 #卡紙 #外徑	14.8	10.5	28	
89	插底型紙盒 #B浪 #外徑	28.5	25.6	24.9	
	PIZZA盒 				
1	8吋PIZZA盒B浪	22	22	3.3	
2	10吋PIZZA盒B浪	27	27	3.3	
3	9吋PIZZA盒B浪	24	24	4.5	
4	12吋PIZZA盒B浪	32	32	4.3	
5	11吋PIZZA盒B浪	30	30	3.3	

6	10吋PIZZA盒 #B浪 #有透氣孔	27	27	4	
7	9吋半PIZZA盒 #B浪 #有透氣孔	25.5	25.5	4.5	
9	7吋PIZZA盒 #B浪 #有透氣孔	17.7	17.9	5	
13	10吋PIZZA盒 #B浪 #有透氣孔	27	27	5	
					
10	六角PIZZA盒_7吋 #B浪 #有透氣孔	19.5	19.5	5	
11	六角PIZZA盒_10吋 #B浪 #有透氣孔	27.5	27.5	5	
12	六角PIZZA盒_12吋 #B浪 #有透氣孔	32.5	32.5	5	
A型/插底+塑膠提把手提盒  					
1	A型底+塑膠提把手 提紙盒#B浪	31	20.8	12.2	
3	A型底+塑膠提把手 提紙盒#B浪	45.6	15.6	26.3	
4	A型底+塑膠提把手 提紙盒#B浪	50.6	30.6	26.4	
5	A型底+塑膠提把手 提紙盒#B浪	21.5	21.5	31.5	
6	A型底+塑膠提把手 提紙盒#B浪	35	24	39.5	
8	插底+塑膠提把手 提紙盒#B浪	31.5	19.8	13.8	
9	A型底+塑膠提把手 提紙盒#B浪	31	18	20	
12	插底+塑膠提把手 提紙盒#B浪	36	27.5	21.9	
14	插底+塑膠提把手 提紙盒#B浪	26.4	13.6	17.4	
15	插底+塑膠提把手 提紙盒#B浪	36.6	20.1	41.2	
16	插底+塑膠提把手 提紙盒#B浪	32.5	16.5	19.5	
17	A型底+塑膠提把手 提紙盒#B浪	26.5	20.1	16.3	
18	插底+塑膠提把手 提紙盒#B浪	50.6	20.8	50.8	
19	插底+塑膠提把手 提紙盒#B浪	28	20	25	
21	插底+塑膠提把手 提紙盒#B浪	31.8	18.2	29.1	
22	插底+塑膠提把手 提紙盒#B浪	51	14	37	
23	插底+塑膠提把手 提紙盒#B浪	50.6	20.8	35.5	
24	插底+塑膠提把手 提紙盒#B浪	25	17	18	
25	插底+塑膠提把手 提紙盒#B浪	34.3	14.3	15.8	
26	插底+塑膠提把手 提紙盒#B浪	30	15.9	15.1	
27	插底+塑膠提把手 提紙盒#B浪	27.3	20.4	17	

	插底手提盒/兩用				
1	插底手提盒#B浪		30.5	10.5	13.5
2	插底手提盒#B浪		30.5	20.5	13.5
3	插底手提盒#B浪 #兩側有透氣孔		28	21	10
5	插底手提盒#B浪 #兩側有透氣孔		29	14.5	8
6	插底手提盒#B浪 #兩側有透氣孔		29.5	22	17.5
7	插底手提盒#B浪		20.5	16.5	14
8	插底手提盒#B浪 #兩側有透氣孔		31.5	18	32
10	插底手提盒#B浪 #兩側有透氣孔		33.6	26.6	13.3
11	插底手提盒#B浪		24	15	11
12	插底手提盒#B浪		20	13	24
13	插底手提盒#B浪		30	24.5	11
14	插底手提盒#B浪 #外徑		30	20	15
16	插底手提盒#B浪		37.5	26.5	11.5
19	插底手提盒#B浪 外徑		37	12.3	18
20	插底手提盒#B浪 外徑 #兩側有透氣孔		26	20	21
21	插底手提盒#B浪 外徑 #兩側有透氣孔		29	14.5	19
22	插底手提盒#B浪 外徑		30	17	18
25	插底手提盒#B浪 外徑		26.2	22.5	18.5
27	插底手提盒#B浪 外徑		21	14.5	25
28	插底手提盒#B浪 外徑		26.5	17	11
29	插底手提盒#B浪 外徑		25.6	11.7	23.3
30	插底手提盒#B浪 外徑		21.5	16.2	14.5
31	插底手提盒#B浪 外徑		42	30	30
32	插底手提盒#B浪 外徑		30	20	23
33	插底手提盒#B浪 外徑		22	20	32.5
34	插底手提盒#B浪 外徑		31.9	15.5	32.1
35	插底手提盒#B浪 外徑		37	23	23
36	插底手提盒#B浪 外徑 兩側有透氣孔		20.8	20.8	21.2
37	插底手提盒#B浪 外徑		23	15	15
38	插底手提盒#B浪 外徑		17.5	10.5	10
39	插底手提盒#B浪 外徑		37	27	24
40	插底手提盒#B浪 外徑		27.5	20	16.5

41	插底手提盒#B浪 外徑		27	19	10	
42	插底手提盒#B浪 外徑		26.8	15.4	16.2	
43	插底手提盒#B浪 外徑		30	20	12.5	
44	插底手提盒#B浪 外徑		26.5	11.9	23	
45	插底手提盒#B浪 外徑		20.5	16.5	14	
A型紙箱 						
4	A型紙箱#B浪		24	17	14	
5	A型紙箱#B浪		29	20	9	
6	A型紙箱#B浪		22	16.5	12	
7	A型紙箱#B浪		26.3	19.2	7.5	
8	A型紙箱#B浪 內徑		22	16.5	6.5	
10	A型紙箱#B浪		23	14	13	
11	A型紙箱#B浪		18	14	13	
12	A型紙箱#B浪		18	14	9.5	
14	A型紙箱#B浪		18	14	6	
16	A型紙箱#B浪 內徑		22	16.5	8.5	
17	A型紙箱#B浪 外徑		30.3	13.8	16	
19	A型紙箱#B浪 外徑		22	15.5	10.5	
21	A型紙箱#B浪 外徑		20	11	16	
22	A型紙箱#B浪 外徑		25.5	21.5	12.4	
24	A型紙箱#B浪 外徑		14.5	8.5	10	
25	A型紙箱#B浪 外徑		20.5	11	14	
26	A型紙箱#B浪 外徑		28	20	12	
27	A型紙箱#B浪 外徑		11	9	7	
28	A型紙箱#B浪 外徑		16	12	20	
30	A型紙箱#B浪 外徑		20	11	19	
31	A型紙箱#B浪 外徑		22	16.5	10	
32	A型紙箱#B浪 外徑		27.5	19.5	12	
33	A型紙箱#B浪 外徑		24	17	14	
34	A型紙箱#B浪 外徑		27	13.8	19.4	
35	A型紙箱#B浪 外徑		23	19	20	
37	A型紙箱#B浪 外徑		16.5	14.5	9.2	
38	A型紙箱#B浪 外徑		24	14	7	

40	A型紙箱#B浪 外徑	23.4	16.5	20	
41	A型紙箱#B浪 外徑	20	11	16	
43	A型紙箱#B浪 外徑	24.5	19	19	
44	A型紙箱#B浪 外徑	25	19	12.5	
45	A型紙箱#B浪 外徑	28	17	31.5	
47	A型紙箱#B浪 外徑	22.5	11	19	
48	A型紙箱#B浪 外徑	33	24	17.5	
49	A型紙箱#B浪 外徑	30	19	10	
50	A型紙箱#B浪 外徑	26.8	19.7	12.7	
51	A型紙箱#B浪 外徑	20	16.9	21.9	
53	A型紙箱#B浪 外徑	18	16.5	28	
55	A型紙箱#B浪 外徑	28	20	11.8	
57	A型紙箱#B浪 外徑	25	13	35	
58	A型紙箱#B浪 外徑	27	21.8	11	
59	A型紙箱#B浪 外徑	25	15	16.5	
60	A型紙箱#B浪 外徑	17.5	17.5	29.2	
61	A型紙箱#B浪 外徑	19.3	10.1	29.1	
63	A型紙箱#B浪 外徑	20	11	22	
64	A型紙箱#B浪 外徑	25	20	15	
66	A型紙箱#B浪 外徑	24.5	16	7	
67	A型紙箱#B浪 外徑	24.6	16	11.5	
68	A型紙箱#B浪 外徑	24.5	16	15.7	
70	A型紙箱#B浪 外徑	25	22	13	
71	A型紙箱#B浪 外徑	22.8	13.1	21.6	
72	A型紙箱#B浪 外徑	32.6	13.5	18.6	
74	A型紙箱#B浪 內徑	23	20	7.6	
75	A型紙箱#B浪 外徑	18	15	15	
76	A型紙箱#B浪 外徑	23	17.9	15.2	
77	A型紙箱#B浪 外徑	16.7	12.6	22.6	
78	A型紙箱#B浪 外徑	15.5	9	11	
79	A型紙箱#B浪 外徑	14.5	11	25.5	
80	A型紙箱#B浪 外徑	20.5	17	30	
81	A型紙箱#B浪 外徑	18.7	18.6	12.1	
82	A型紙箱#B浪 外徑	22	13	13	

83	A型紙箱#B浪 外徑	22	18	12	
84	A型紙箱#B浪 外徑	32	25	15	
85	A型紙箱#B浪 外徑	26	19	10	
86	A型紙箱#B浪 外徑	20	16	11	
88	A型紙箱#B浪 外徑	20	18	10	
89	A型紙箱#B浪 外徑	18	16.5	31	
90	A型紙箱#B浪 外徑	10	10	34.5	
91	A型紙箱#B浪 外徑	20	10	34.5	
92	A型紙箱#B浪 外徑	23	13	15.5	
93	A型 插底 紙箱#B浪 外徑	25	20	15	
94	A型紙箱#B浪 外徑	26	17	14.5	
95	A型紙箱#B浪 外徑	20	20	34.5	
96	A型紙箱#B浪 外徑	20	11	21	
97	A型紙箱#B浪 外徑	23.2	19	15.2	
98	A型紙箱#B浪 外徑	19	12.9	15.2	
99	A型 插底 紙箱#B浪 外徑	19	18	11	
100	A型紙箱#B浪 外徑	15.6	12	19.7	
101	A型紙箱#B浪 外徑	13.6	13.6	14.1	
102	A型紙箱#B浪 外徑	23	20	14	
103	A型紙箱#B浪 外徑	25	18	10	
104	A型紙箱#B浪 外徑	27	20	13	
105	A型紙箱#B浪 外徑	19.1	14.2	13.6	
106	A型紙箱#B浪 外徑	22.4	22.4	12	
107	A型紙箱#B浪 外徑	20.9	18.1	22.8	
108	A型紙箱#B浪 外徑	17.7	14.6	12	
109	A型紙箱#B浪 外徑	26	17	17	
110	A型紙箱#B浪 外徑	37	17.5	9	
111	A型紙箱#A浪 外徑	20	20	20	
112	A型紙箱#B浪 外徑	20	11.5	8.7	
113	A型紙箱#B浪 外徑	16.1	13.9	22.1	
114	A型紙箱#B浪 外徑	23	18	15	
蛋糕盒					
1	雙月型手提盒 #B浪	24.8	9.3	7.7	

2	雙月型手提盒 #B浪		21	21	10	
	球棒/雨傘 紙盒					
1	雨傘紙盒#B浪		11.3	6.5	95.5	
2	雨傘紙盒#B浪		11.3	6.5	78	
	雙頭插蓋紙盒					
2	雙頭插蓋紙盒 #卡紙		15.4	15.4	8	
3	雙頭插蓋紙盒 #卡紙		13.2	13.2	15.2	
4	雙頭插蓋紙盒 #卡紙		3.8	3.2	8.6	
5	雙頭插蓋紙盒 #E浪		10	10	5	
8	雙頭插蓋紙盒 #B浪		11	11	60	
9	雙頭插蓋紙盒 #卡紙		14	3.5	22.4	
11	雙頭插蓋紙盒 #B浪		14.5	6.5	25	
13	雙頭插蓋紙盒 #卡紙		8	6.5	22.6	
16	雙頭插蓋紙盒 #F浪		4.75	4.75	14.3	
20	雙頭插蓋紙盒 #F浪		8.8	8.8	7.5	
21	雙頭插蓋紙盒 #卡紙		3.7	3.7	10	
22	雙頭插蓋紙盒 #卡紙		4.6	4.6	17	
24	雙頭插蓋紙盒 #卡紙		18.8	8.2	25.9	
26	雙頭插蓋紙盒 #卡紙		2.4	2.4	9.3	
27	雙頭插蓋紙盒 #卡紙		2.4	2.4	12.8	
28	雙頭插蓋紙盒 #卡紙		13.5	3.4	4.8	
29	雙頭插蓋紙盒 #卡紙		2.5	2.5	7.4	
30	雙頭插蓋紙盒 #卡紙		6	3	8.5	
31	雙頭插蓋紙盒 #卡紙		2.4	2.6	9.3	
32	雙頭插蓋紙盒 #B浪		40.7	18.6	61	
33	雙頭插蓋紙盒 #F浪		5.1	5.1	16.9	
34	雙頭插蓋紙盒 #E浪		21.6	9.1	43.3	
35	雙頭插蓋紙盒 #B浪		27	3.5	31.9	
36	雙頭插蓋紙盒 #B浪		40.4	6	53.1	
37	雙頭插蓋紙盒 #卡紙		12.3	3.4	12.3	
38	雙頭插蓋紙盒 #卡紙		10.7	4.6	10.4	
39	雙頭插蓋紙盒 #卡紙		2.9	2.9	11.4	

40	雙頭插蓋紙盒 #卡紙		7.5	7.5	11.3	
	十字型手提盒					
1	十字型手提盒 #E浪		28	28	10	
	上下蓋(天地盒)					
1	上下蓋(外徑) #E浪		30.7	26.7	8.5	
3	上下蓋(外徑) #上E浪 #下B浪		32.1	25.1	12	
7	上下蓋(外徑) #上E浪 #下B浪		35.5	25.5	12	
11	上下蓋(內徑) #上E浪 #下B浪		33	23.5	11	
12	上下蓋(內徑) #上E浪 #下B浪		48.5	31	11	
13	上下蓋(內徑) #上E浪 #下B浪		33	23.5	12	
15	上下蓋(外徑) #卡紙		17.1	17.1	6.5	
19	上下蓋(外徑) #上卡紙 #下B浪		31.1	27.2	17.4	
20	上下蓋(外徑) #E浪		28.6	20.3	9	
21	上下蓋(外徑) #卡紙 #蛋糕推薦		21	12	10	
22	上下蓋(外徑) #上卡紙 #下E浪		37.6	28.8	9.1	

*備註: 可印上屬於自己公司的logo 設計 / 也可客製化尺寸